




Single Screw MJ500/MP500 SERIES

WIRE ASSEMBLY INSTRUCTIONS


(Follow Same Instructions For All Available Calibrations)



WIRE PREPARATION

Strip Exposed Wires $5/16''$ (inch)
Exposing Bare Wire.

NOTE: If your wire has an outer jacket
remove $1/2''$ (inch) of it, exposing the
positive and negative wires.



*Wire Without
Outer Jacket*



*Wire With
Outer Jacket*




Need Help or Have Questions? Call (800) 582-5098

LOOSEN CAP SCREW

2

Loosen the connectors single screw with a **#1 Phillips Screwdriver**, then remove the cap.

NOTE: The same steps apply for both the **MP500** and **MJ500** connectors.






Need Help or Have Questions? Call (800) 582-5098

REMOVING THE CAP

Once the cap is removed, place it in a safe location off to the side.

NOTE: The cap design is universal for both the **MP500** and **MJ500** connectors.



Built In Grommet



Need Help or Have Questions? Call (800) 582-5098


STEP THREE | REMOVING THE CAP

INSERTING THE WIRE

4

Spread stripped wires, helping them hold a “V” shape. Then insert them through the guide holes located above the eraser colored grommet.

NOTE: Spreading the wire to hold a “V” shape will keep the wire from trying to go back to its original form, thus pushing itself back out of the guide holes.






Need Help or Have Questions? Call (800) 582-5098

REINSTALL THE CAP

5

Firmly but carefully hold your wire in place, then reinstall the cap and tighten the single screw.

NOTE: Before you reinstall the cap make sure you have the proper polarity based on your application needs.





Need Help or Have Questions? Call (800) 582-5098



Made in Michigan
ISO 9001 REGISTERED

TEMPREL
temperature sensors

www.temprel.com

206 Industrial Pkwy Dr.
Boyne City, MI 49712

Phone: (800) 582-5098
Fax: (231) 582-9491

Version (1)
2023